

## **Installing Schlage Pad**

This new schlagel corner pad seals the door's weather-strip, preventing water from percolating up and over the threshold.

To install new pads open the door, and remove backing from schlagel pad and place at bottom of hinge side of jamb at threshold, tucking the raised fin of the corner pad under the weather strip. This can also be done to the strike side of the jamb. To insure proper adhesion make sure the jamb is clean and dry before applying.

Making sure the schlagel pads are in place and in good shape is essential to maintaining a weatherproof door. To replace damaged pads, simply peel the old pads off the frame or, if necessary, a putty knife can be used to scrape the old pad off, and follow the above instructions.



