

Adjust Sweeps

To adjust the sweep on the bottom of an exterior door, take a screwdriver and loosen the screws holding the sweep onto the door. You can then slide the sweep up or down to adjust accordingly.

